

TunnelWatch TCS2 to Unitec Interface Wiring:

Tunnel Control Station Input Wiring

1. Connect the Unitec relay common (Pin 9 on terminal block J17) to one of the SRC (lower) terminals of the Tunnel Control Station inputs.
 - a. It does not matter which of the COM terminals is used. All of the COM terminals are supplied from the same 24v source.
2. Connect the Unitec wash outputs (Pins 1 through 4 on terminal block J17) to the Input (upper) terminals of the Tunnel Control Station inputs 1E through 1H.
 - a. On the Portal TI, terminal block J17 is on the Wash Interface board (bottom board on right internal wall).
 - b. On the Wash Select II, terminal block J17 is on the CPU board (large board on right internal wall).
3. [Tunnel Control Station Input Wiring for Unitec Interface.](#)

